

Method card

BUZIL-WERK Wagner GmbH & Co. KG

CORRIDOR® MATT S 737

Application area:
Floor / coating



pH 7.5

Dilution	pure		
Suitable for	Health facilities, old people's homes and care homes; Hospitals, sports halls	Not suitable for	Textile surfaces; Unsealed parquet
Application	Water-resistant floor coverings; Linoleum; PVC; Rubber		
 Trouble Shooting Before initial use: Test material compatibility!	Issue / Failure / Requirement	Solving Issue	
	<ul style="list-style-type: none"> ▪ Poor penetration / shine ▪ Foaming with „craters“ as a result after drying ▪ Powdering off when used ▪ Severe marking when used ▪ Grey / mat appearance of surface due to hard water ▪ Damage on surface (discoloration, material swelling, etc.) 	<ul style="list-style-type: none"> ▪ Covering too porous, apply pore filler / another layer ▪ Covering too rough, spread more slowly when applying ▪ Before applying, do not let the covering dry / deep clean again ▪ Intensive cleaning with Maradin HC 43, Aktiv G 433, spray cleaning with Corridor® Spray S 770 ▪ Clean periodically with O Tens Azid G 501 ▪ Check material's chemical and water resistance 	

Method card

BUZIL-WERK Wagner GmbH & Co. KG

ALTERNATIVE PRODUCT | CORRIDOR® MATT S 737

Application area:
Floor / coating



pH 7.5

Alternative Product	Differentiation	Application
Planta® Multi Gloss P 320	Eco certified, glossy, no DIN 18032/2 certification	Glossy floor coating, not on sports flooring
Corridor® Complete S 732	Contains metallic salts, glossy, no DIN 18032/2 certification	Glossy floor coating, not on sports flooring
Corridor® Glorin S 734	Glossy, no DIN 18032/2 certification	Glossy floor coating, not on sports flooring
Corridor® Jewel S 741	More shine	High-gloss floor coating